

### Installing Worktop

#### Stock No. 33171, 33172, 33178, 33180, 33182, 33192, 33203, 33210

To make assembly easier we recommend having two persons aid one another in assembly.

Place the worktop on cabinets, align the pre-drilled holes in worktop with holes in cabinets, secure bolt M6 x 16mm through the top of the cabinets into the worktop pre-drilled holes.







#### Installing Back Panel / Wall Cabinet with Wall Brackets (Single & Double)

Stock No. **33196 / 33162** 

To make assembly easier we recommend having two persons aid one another in assembly.

#### STEP 1:

Attach wall bracket (single and double) to cabinet with bolt M8 x16mm, washer  $18 \times 8 \times 1$ mm and spring washer  $14 \times 8.8 \times 2.6$ mm, and tighten with wrench (not included).

#### STEP 2:

Attach back panel to wall bracket (single and double) with bolt M6 x 16mm, nut M6 and spring washer 12 x 6.5 x 0.8mm, and tighten with wrench (not included).





#### STEP 3:

Attach wall cabinet to wall bracket (single and double) with bolt M8 x 16mm, flat washer 8 x 8 x 1mm and spring washer 14 x 8.8 x 2.6mm, and tighten with wrench (not included)



#### STEP 4:

Connect the side panels of two cabinets with M6 x 16mm and nut M6, and tighten with wrench (not included).



#### **CABINET CONNECTION**

Connect the side panels of two cabinets with (4) bolt M6 x 16mm and nut M6, and tighten with wrench (not included).

**Note:** remove the drawers and open the doors before cabinet connection.







# BUALER TOOLS

## Installing Wall Bracket

## Stock No. **33197, 33198**

- Attach wall bracket (double) to back panel with (10) bolt M6 x 16mm, nut M6 and flat washer 12 x 6.5 x 0.8mm, and tighten with wrench (not included).
- Attach wall bracket (double) to wall cabinets and base cabinets / trolley with (8) bolt M8 x 16mm, flat washer 18 x 8 x 1mm and spring washer 14 x 8.8 x 2.6mm, and tighten with wrench (not included).
- Attach wall bracket (single) to back panel with (5) bolt M6 x 16mm, nut M6 and flat washer 12 x 6.5 x 0.8mm, and tighten with wrench (not included).
- Attach wall bracket (single) to wall cabinets and base cabinets / trolley with (4) bolt M8 x 16mm, flat washer 18 x 8 x 1mm and spring washer 14 x 8.8 x 2.6mm, and tighten with wrench (not included).



